

## **Disc Antenna Installation Tips**

- Position away from:
  - CRT/TVs
  - lighting fixtures
  - motors
  - other wireless devices
  - large vertical metal or concrete objects
  - Low-E or tinted/coated windows
- Drill a 0.5 inch (12 mm) diameter hole in a horizontal flat surface
- Remove mounting nut & washer and feed coax cable through hole
- Remove bottom plastic liner to expose adhesive
- Press antenna into hole and tighten nut & washer from underneath
- Optionally apply a thin bead of silicone caulk around the antenna rim
- Use 2 identical antennas spaced 22 inches apart if modem/AP supports diversity or MIMO